



WOCD Installation Instructions

Tools Needed:

- Drill with Phillips tip
- ¼" drill bit
- Pencil
- Tape measure

Contents:

- WOCD (Left or Right)
- Screws (4 pairs)
- Backing Plate
- Shims (3 pcs)

Installation:

The WOCD package comes with three shims and four pairs of screws for installation on different types of windows.

To install on a 1000 series window, use one shim and the 3/8" screws. The 3000 series does not need shims and uses the same 3/8" screws (second screw from the left, Pic. 1)

1. Open the sash 3 ¾" (Pic. 2)
2. Place the WOCD on the edge of the frame and against the sash (Pic. 3)
3. Use the pencil to mark holes for drilling (Pic. 4)
4. Close and lock the sash
5. Use the ¼" drill bit to drill out the holes. Drill slowly to avoid damage to the slider track
6. Install the backing plate (Pic.5)
7. Attach the WOCD to the backing plate using the supplied screws (Pic. 6)

1



2



3



4



5



6

