



Window Touch Up Procedure

Royal Bond Euro Finish

- Ensure the affected area is clean and free of any loose paint or debris.
- Use the brush in the touch up bottle to apply a small amount of paint to the area.
- Use the finger sponge to blend.
- Wait 15 minutes for the first coat to dry.
- Apply and blend a second coat as needed.





Chip / Scratch in Euro Finish



Chip /Scratch immediately after touch-up.

